

Código	Descrição	Desenho
CT9-B5-311	CONTATOR TRIPOLAR 11A/AC3 - BOB: 24VCA - AUX: 1NA+1NF	CT_9_12_22_AC.STEP
CT9-E5-311	CONTATOR TRIPOLAR 11A/AC3 - BOB: 110VCA - AUX: 1NA+1NF	CT_9_12_22_AC.STEP
CT9-H5-311	CONTATOR TRIPOLAR 11A/AC3 - BOB: 220VCA - AUX: 1NA+1NF	CT_9_12_22_AC.STEP
CT9-L5-311	CONTATOR TRIPOLAR 11A/AC3 - BOB: 380VCA - AUX: 1NA+1NF	CT_9_12_22_AC.STEP
CT9-B0-311	CONTATOR TRIPOLAR 11A/AC3 - BOB: 24VCC - AUX: 1NA+1NF	CT_9_12_22_DC.STEP
CT12-B5-311	CONTATOR TRIPOLAR 13A/AC3 - BOB: 24VCA - AUX: 1NA+1NF	CT_9_12_22_AC.STEP
CT12-E5-311	CONTATOR TRIPOLAR 13A/AC3 - BOB: 110VCA - AUX: 1NA+1NF	CT_9_12_22_AC.STEP
CT12-H5-311	CONTATOR TRIPOLAR 13A/AC3 - BOB: 220VCA - AUX: 1NA+1NF	CT_9_12_22_AC.STEP
CT12-L5-311	CONTATOR TRIPOLAR 13A/AC3 - BOB: 380VCA - AUX: 1NA+1NF	CT_9_12_22_AC.STEP
CT12-B0-311	CONTATOR TRIPOLAR 13A/AC3 - BOB: 24VCC - AUX: 1NA+1NF	CT_9_12_22_DC.STEP
CT22-B5-311	CONTATOR TRIPOLAR 22A/AC3 - BOB: 24VCA - AUX: 1NA+1NF	CT_9_12_22_AC.STEP
CT22-C5-311	CONTATOR TRIPOLAR 22A/AC3 - BOB: 48VCA - AUX: 1NA+1NF	CT_9_12_22_AC.STEP
CT22-E5-311	CONTATOR TRIPOLAR 22A/AC3 - BOB: 110VCA - AUX: 1NA+1NF	CT_9_12_22_AC.STEP
CT22-H5-311	CONTATOR TRIPOLAR 22A/AC3 - BOB: 220VCA - AUX: 1NA+1NF	CT_9_12_22_AC.STEP
CT22-L5-311	CONTATOR TRIPOLAR 22A/AC3 - BOB: 380VCA - AUX: 1NA+1NF	CT_9_12_22_AC.STEP
CT22-O5-311	CONTATOR TRIPOLAR 22A/AC3 - BOB: 440VCA - AUX: 1NA+1NF	CT_9_12_22_AC.STEP
CT22-B0-311	CONTATOR TRIPOLAR 22A/AC3 - BOB: 24VCC - AUX: 1NA+1NF	CT_9_12_22_DC.STEP